

PART LIST - GT4RSB-S

<i>Ref</i>	<i>Description</i>	<i>Part No.</i>	<i>Qty</i>	<i>Ref</i>	<i>Description</i>	<i>Part No.</i>	<i>Qty</i>
1	Lid Assembly	P0014742E4	1	40	Side Shelf, Left	P011020684	1
2	Temperature Gauge	P00601484C	1	41	Side Burner Mounting Brakcet	P03327024D	1
3	Lid Handle	P00218014R	1	42	Side Burner	P02004043F	1
4	Lid Handle Seat (Left)	P03303124A	1	43	Electrode- Side Burner	P02607060C	1
5	Lid Handle Seat (Right)	P03303125A	1	44	Side Shelf Body	P011030612	1
6	Lid Rubber Pad	P05518002I	4	45	Rear Burner Valve Orifice-30mbar	P06531001A	1
7	Name plate	P00407036A	1	46	Control Knob - side burner	P03408101L	1
8	Bowl Set	P0076703B4	1	47	Valve- Side Burner	P03250007G	1
9	Bowl Grease Shield	P06901030B	2	48	Adaptor-1/4 LH inlet	P03904002A	1
10	Burner Bracket-Side Burner	P03303150U	1	49	Side Shelf Trim Plate	P011260244	1
11	Heat Shield- Rear Burner	P06905080B	1	51	Valve - Rear Burner- without jet	P03239013A	1
12	Grill Plate	P01615052H	3	50	Rear Burner Body Set	P02007072A	1
13	Bowl Wind Shield	P0074808R4	1	52	Wind Shield - Rear Burner	P069060824	1
14	Gas Collector Box with Electrode	P02609055A	3	53	Aluminum tube- Rear Burner	P03717065B	1
15	Electric Wire Set	P02615197A	1Set	54	Door guid - upper	P055101454	1
16	Main Burner	P02008085B	3	55	Trolley Panel, Left	P076170524	1
17	Knob Seat Spring	P05504021A	5	56	Trolley Panel, Right	P076180554	1
18	Quick connect , female	P03912001A	1	57	Door-Guide-Upper	P033020404	1
19	Upper control Panel-30mbar	P81109332J	1	58	Door-Guide - Lower	P055101414	1
	Upper control Panel-50mbar	P81109333J	1	59	Magnet seat	P05523001K	4
20	Control Panel	P0291592IS	1	60	2.5" caster	P05118004A	4
21	Gas Valve Heat Shield	P0300819DG	1	61	Door-L	P043020634	1
22	Main Valve-without jet	P03239012A	3	62	Gas cylinder housing	P04021013H	1
23	Manifold	P05006162A	1	63	Trolley Bottom Panel	P010090464	1
24	Gas Valve Heat Shield Bracket	P03327107A	2	64	Trolley Panel, Rear	P076240054	1
25	Control knob - main burner	P03401477K	3	65	Door-R	P043030634	1
26	Knob Seat	P03415014S	5	66	Tank Fastening Strap	P05314005V	1
27	Control knob - Back burner	P03436147A	1	67	Tank holder	P04009036C	2
28	Electric Ignitor	P02502265C	1	68	Searing Burner Electrode	P02614061A	1
29	Grease Tray Handle	P00213039M	1	69	Searing Burner	P02005032A	1
30	Grease Tray Holder Bracket	P03327111D	1	70	Searing Burner Heat Shield	P0077002B4	1
31	Grease Tray	P02717837D	1	71	Searing Valve-without jet	P032480095	1
32	Hotplate	P05701049H	1	72	Searing Burner Electrode Bracket	P033271154	1
33	Side burner hose bracket	P03341002Q	2	73	Control knob - Searing burner	P03436147A	1
34	Electrode- Rear Burner	P02614025A	1	74	Universal Hose Bar -1/4 LH inlet	P03901024A	1
35	Warming Rack	P01516030K	1		Hardware Pack	P06028033A	1
36	Crossfire box	P022123984	2				
37	Quick connect with hose, male	P03711041I	1				
38	Side Shelf Lid	P0011555E4	1				
39	Side Shelf Pot Support	P00815008A	1				

GT4RSB-S Model

This diagram is provided to assist you identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to inquire about parts, availability and service.

Items included in your barbecue specification may differ from the parts list, depending on region or specific dealer specification.

